
How to change fuel filter on **AUDI TT Coupe (8N3)** – replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:
AUDI TT Coupe (8N3) 1.8 T, AUDI TT Coupe (8N3) 1.8 T quattro, AUDI TT Coupe (8N3) 3.2 VR6 quattro

---

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: AUDI A3 Hatchback (8L1) 1.8

REPLACEMENT: FUEL FILTER – AUDI TT COUPE (8N3).
LIST OF THE TOOLS YOU'LL NEED:



- Drive socket # 10
- Flat screwdriver
- Fluid container

Buy tools

Replacement: fuel filter – AUDI TT Coupe (8N3). AUTODOC experts recommend:

- Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.
- All work should be done with the engine stopped.


REPLACEMENT: FUEL FILTER – AUDI TT COUPE (8N3). USE THE FOLLOWING PROCEDURE:

1 Open the fuel door. Unscrew the fuel filler cap.




2 Lift the car and set it on jack stands.

3 Prepare a container for fluids.



4 Unscrew the fastener of the fuel filter holder. Use a drive socket #10.



5

Squeeze the clips and detach the fuel supply lines from the fuel filter housing. Use a flat screwdriver.




Replacement: fuel filter – AUDI TT Coupe (8N3). Tip:

- Be careful! Fuel may leak from the filter housing and hoses.

6

Remove the fuel filter. Put the old filter cartridge in the container.



7

Install a new fuel filter.



Replacement: fuel filter – AUDI TT Coupe (8N3). Tip from AUTODOC:

- Remember, it is important not to mix up the input and output of the filter. Arrows on the filter indicate the direction of fuel flow.
- During installation, take care to prevent dust and dirt from getting into the fuel filter housing.
- AUDI TT Coupe (8N3) – It's important to only use high-quality filters.

8 Connect the fuel lines to the fuel filter and lock the fastening clips.



9 Tighten the fuel filter fasteners. Use a drive socket #10.




10 Take the fluid container away from under the fuel filter.

11 Lower the car.

12

Tighten the fuel filler cap. Close the fuel door.



Replacement: fuel filter – AUDI TT Coupe (8N3). Professionals recommend:

- Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.

13

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

Replacement: fuel filter – AUDI TT Coupe (8N3). AUTODOC recommends:

- To protect the environment from pollution, be sure to dispose of the used filters at special collection points.

WELL DONE!

VIEW MORE TUTORIALS

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

FUEL FILTER: A WIDE SELECTION

ⓘ DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.